# FCC TEST REPORT

FCC ID :WGBXL4432TB

Applicant : Logic Gear (HK) Ltd.

1430, Floor 14, Sing Win Factory Building 15-17 Shing Yip Street Kwun

Tong Kowloon Hong Kong

**Equipment Under Test (EUT):** 

Product description : Pocketable GPS

Model No : XL4431,XL4432,XL4431B,XL4432B,XL4431T,

XL4432T,XL4431TB,XL4432TB

**Standards** : FCC 15 Paragraph 15.247

**Date of Test** : July 3, 2008

**Test Engineer** : Nunu.Deng

Reviewed By: Thelo 2hous

PERPARED BY:

Waltek Services (Shenzhen) Co., Ltd.

1/F, Fukangtai Building, West Baima Rd., Songgang Street, Baoan District, Shenzhen 518105, China

Tel: 86-755-27553488

Fax: 86-755-27553868

# 2 Contents

			Page
1	C	COVER PAGE	1
2	C	CONTENTS	2
3	T	EST SUMMARY	4
4	G	GENERAL INFORMATION	5
	4.1	CLIENT INFORMATION	
	4.2	GENERAL DESCRIPTION OF E.U.T.	
	4.3	DETAILS OF E.U.T.	
	4.4	DESCRIPTION OF SUPPORT UNITS	
	4.5	STANDARDS APPLICABLE FOR TESTING	
	4.6	TEST FACILITY	
	4.7	TEST LOCATION	
5	E	QUIPMENT USED DURING TEST	7
6	C	CONDUCTED EMISSION TEST	9
	6.1	TEST EQUIPMENT	9
	6.2	TEST PROCEDURE	
	6.3	CONDUCTED TEST SETUP	10
	6.4	EUT OPERATING CONDITION	10
	6.5	CONDUCTED EMISSION LIMITS	
	6.6	CONDUCTION RADIATION TEST RESULT	
		.6.1 Conducted Emissions Test Data	
7	R	ADIATION EMISSION TEST	14
	7.1	TEST EQUIPMENT	
	7.2	MEASUREMENT UNCERTAINTY	
	7.3	TEST PROCEDURE	
	7.4	RADIATED TEST SETUP	
	7.5	SPECTRUM ANALYZER SETUP	
	7.6	CORRECTED AMPLITUDE & MARGIN CALCULATION	
	7.7	SUMMARY OF TEST RESULTS	
	7.8	EUT OPERATING CONDITION	
	7.9 7.10		
	7.10		
8		NTENNA REQUIREMENT	
		•	
9	N	MAXIMUM PEAK OUTPUT POWER	24
1	0 H	IOPPING CHANNEL NUMBER	25
1	1 C	CARRIER FREQUENCIES SEPARATED	26

11.1	MIDDLE CHANNEL: CARRIER FREQUENCIES SEPARATED	
11.3	UPPER CHANNEL: CARRIER FREQUENCIES SEPARATED	
12 DW	VELL TIME	29
12.1	TEST PROCEDURE	29
12.2	TEST RESULTS: PASS	29
13 20-	DB BANDWITH	32
13.1	Test Procedure	32
13.2	TEST RESULT	33
14 RA	DIATED SPURIOUS EMISSIONS INTO ADJACENT RESTRICTED BAND	35
15 RF	EXPOSURE TEST	37
16 PH	OTOGRAPHS OF TESTING	39
16.1	RADIATION EMISSION TEST VIEW FOR 30MHz-1000MHz	39
16.2	RADIATION EMISSION TEST VIEW FOR 1GHz-25GHz	
16.3	PHOTOGRAPHS - CONDUCTION RADIATION TEST SETUP	40
17 PH	OTOGRAPHS - CONSTRUCTIONAL DETAILS	41
17.1	EUT- Front View	41
17.2	EUT-BACK VIEW	41
17.3	EUT PCB –Front View	42
17.4	EUT PCB –BACK VIEW	42
17.5	EUT PCB –Front View	43
17.6	EUT PCB –BACK VIEW	43
17.7	Adapter PCB– Front View	44
17.8	Adapter PCB–Back View	
17.9	CAR CHARGER ADAPTER PCB –FRONT VIEW	45
17.10	CAR CHARGER ADAPTER PCB–BACK VIEW	45
18 FC	C ID LARFL	46

# 3 Test Summary

Test	Test Requirement	Test Method	Class / Severity	Result
Radiated Emission (30MHz to 25GHz)	FCC PART 15: 2003	ANSI C63.4: 2003	N/A	PASS
Conducted Emission (150KHz to 30MHz)	FCC PART 15: 2003	ANSI C63.4: 2003	N/A	PASS

### FCC ID: WGBXL4432TB

### 4 General Information

#### 4.1 Client Information

Applicant: Logic Gear (HK) Ltd.

Address of Applicant: 1430, Floor 14, Sing Win Factory Building 15-17 Shing Yip

Street Kwun Tong Kowloon Hong Kong

### **4.2** General Description of E.U.T.

Product description: Pocketable GPS

Model No.: XL4431,XL4432,XL4431B,XL4432B,XL4431T,

XL4432T,XL4431TB,XL4432TB

#### 4.3 Details of E.U.T.

Power Supply: Adapter input:100~240V AC 50/60Hz

Adapter output: DC 6V Car Charger Input:DC 12V Battery Input DC 3.7V

### 4.4 Description of Support Units

The EUT has been tested as an independent unit.

### 4.5 Standards Applicable for Testing

The customer requested FCC tests for a Pocketable GPS. The standards used were FCC 15 Paragraph 15.247,Paragraph 15.205, Paragraph 15.207,Paragraph 15.209, Paragraph 15.31,Paragraph 15.33, Paragraph 15.35.

### 4.6 Test Facility

The test facility is recognized, certified, or accredited by the following organizations:

### • FCC – Registration No.: 880581

Waltek Services(Shenzhen) Co., Ltd. EMC Laboratory has been registered and fully described in a report filed with the (FCC) Federal Communications Commission. The acceptance letter from the FCC is maintained in our files. Registration 880581.June 24,2008.

### 4.7 Test Location

All Emissions testswere performed at:-1/F, Fukangtai Building, West Baima Rd., Songgang Street, Baoan District, Shenzhen 518105, China

# 5 Equipment Used during Test

Equipment	Brand Name	Model	Related standards	Cal.Intal  Months	Last Cal.	Serial No					
3m Anechoic chamber											
EMC Analyzer	Agilent	E7405A	ISO9001:2000	12	Jan-08	MY4511494 3					
Trilog Broadband Antenne 30-3000	SCHWARZB ECK MESS-	VULB9163	EN/ISO/IEC 17025 DIN	12	Jan-08	336					
MHz	ELEKTROM		EN ISO9001								
Broad-band Horn Antenna	SCHWARZB ECK MESS- ELEKTROM	BBHA 9120 D	EN/ISO/IEC 17025 DIN EN ISO9001	12	Jan-08	667					
Broadband Preamplifier	SCHWARZB ECK MESS- ELEKTROM	BBV 9718	EN/ISO/IEC 17025 DIN EN ISO9001	12	Jan-08	9718-148					
10m Coaxial Cable with N-male Connectors	SCHWARZB ECK MESS- ELEKTROM	AK 9515 H	EN/ISO/IEC 17025 DIN EN ISO9001	12	Jan-08	-					
10m 50 Ohm Coaxial Cable with N- plug,individual length,usable up to 3(5)GHz, Connectors	SCHWARZB ECK MESS- ELEKTROM	AK 9513	EN/ISO/IEC 17025 DIN EN ISO9001	12	Jan-08	-					
Positioning Controller	C&C LAB	CC-C-IF	ISO9001	12	Jan-08	MF7802108					
Color Monitor	SUNSPO	SP-14C	ISO9001	12	Jan-08	-					
EMI Shielded Room	561,51	51 1.0	1509001	12	T van						
Test Receiver	ROHDE&SC HWARZ	ESPI	ISO9001	12	Jan-08	101155					
Two-Line V-Network	ROHDE&SC HWARZ	ENV216	ISO9001 EN/ISO/IEC 17025	12	Jan-08	100115					
Absorbing Clamp	ROHDE&SC HWARZ	MDS-21	ISO9001 EN/ISO/IEC 17025	12	Jan-08	100205					
10m 50 Ohm Coaxial	SCHWARZB	AK 9514	EN/ISO/IEC	12	Jan-08	-					

Cable with N-	ECK MESS-	17025 DIN		
plug,individual	ELEKTROM	EN ISO9001		
length,usable up to				
3(5)GHz, Connectors				

### 6 Conducted Emission Test

Test Requirement: FCC Part15 Paragraph 15.207

Test Method: Based on FCC Part15 Paragraph 15.207

Test Date: July 3, 2008

Frequency Range: 150kHz to 30MHz

Class B

Detector: Peak for pre-scan (9kHz Resolution Bandwidth)

Quasi-Peak & Average if maximised peak within 6dB of

Average Limit

### 6.1 Test Equipment


Please refer to Section 5 this report.

#### **6.2** Test Procedure

- 1. The EUT was connected with signal generator and placed on a table.
- 2. The EUT was tested according to ANSI C63.4:2003. The frequency spectrum from 150kHz to 30MHz was investigated.
- 3. The maximised peak emissions from the EUT was scanned and measured for both the Live and Neutral Lines. Quasi-peak & average measurements were performed if peak emissions were within 6dB of the average limit line.

### **6.3** Conducted Test Setup


The conducted emission tests were performed using the setup accordance with the ANSI C63.4:2003, The specification used in this report was the FCC Part15 Paragraph 15.207 limits.



### **6.4 EUT Operating Condition**

Operating condition is according to ANSI C63.4:2003.

- A. Setup the EUT and simulators as shown on follow.
- B. Enable RF signal and confirm EUT active.
- C. Modulate output capacity of EUT up to specification.





### **6.5** Conducted Emission Limits

 $66\text{-}56~dB\mu V/m$  between 0.15MHz~&~0.5MHz  $56~dB\mu V/m$  between 0.5MHz~&~5MHz  $60~dB\mu V/m$  between 5MHz~&~30MHz

**Note**: In the above limits, the tighter limit applies at the band edges.

### **6.6** Conduction Radiation Test Result





### **6.6.1 Conducted Emissions Test Data**

Freq. MHz	Line	QP Level dBuV	Limit dBuV	Margin dB	AV Level dBuV	Limit dBuV	Margin dB
0.178	Live	54.15	64.59	10.44	36.92	57.15	20.23
0.362	Live	48.76	58.73	9.97	31.74	49.49	17.75
0.658	Live	49.13	56.00	6.87	34.28	46.00	11.72
0.77	Live	47.82	56.00	8.18	33.67	46.00	12.33
1.62	Live	46.52	56.00	9.48	31.67	46.00	14.33
5.05	Live	41.42	60.00	18.58	26.37	50.00	23.63
0.178	Neutra	54.82	64.59	9.77	49.11	57.15	8.04
0.242	Neutra	52.37	62.05	9.68	43.16	53.84	10.68
0.402	Neutral	50.15	57.87	7.72	34.35	48.36	14.01
0.65	Neutral	52.13	56.00	3.87	40.08	46.00	5.92
1.32	Neutral	45.75	56.00	10.25	31.29	46.00	14.71
5.19	Neutral	45.58	60.00	14.42	31.55	50.00	18.45

### 7 Radiation Emission Test

Test Requirement: FCC Part15 Paragraph 15.247
Test Method: Based on ANSI 63.4:2003

Test Date: July 3, 2008

Frequency Range: 30MHz to 25GHz

Measurement Distance: 3m

Detector: Peak for pre-scan (120kHz resolution bandwidth)

Quasi-Peak if maximised peak within 6dB of limit

### 7.1 Test Equipment

Please refer to Section 5 this report.

#### 7.2 Measurement Uncertainty

All measurements involve certain levels of uncertainties, especially in the field of EMC. The factors contributing to uncertainties are spectrum analyzer, cable loss, antenna factor calibration, antenna directivity, antenna factor variation with height, antenna phase center variation, antenna factor frequency interpolation, measurement distance variation, site imperfections, mismatch (average), and system repeatability.


Based on ANSI C63.4:2003, The Treatment of Uncertainty in EMC Measurements, the best estimate of the uncertainty of a radiation emissions measurement at . Waltek EMC Lab is +4.0 dB.

#### 7.3 Test Procedure

- 1. The EUT was connected with signal generator and placed on a table.
- 2. Maximizing procedure was performed on the six (6) highest emissions to ensure EUT is compliant with all installation combinations.
- 3. All data was recorded in the peak and average detection mode.
- 4. The EUT was under normal mode during the final qualification test and the configuration was used to represent the worst case results.

### 7.4 Radiated Test Setup

The radiated emission tests were performed in the 3m Semi- Anechoic Chamber test site, using the setup accordance with the ANSI C63.4:2003, The specification used in this report was the FCC Part15 Paragraph 15.209 limits and Paragraph 15.247 limits.



### 7.5 Spectrum Analyzer Setup

According to FCC Part15 Paragraph 15.247 Rules, the system was tested to 25000 MHz.

Start Frequency	30 MHz
Stop Frequency	25000 MHz
Sweep Speed Auto	
IF Bandwidth	100 kHz
Video Bandwidth	1 MHz
Quasi-Peak Adapter Bandwidth	120 kHz
Quasi-Peak Adapter Mode	Normal
Resolution Bandwidth	1MHz

### 7.6 Corrected Amplitude & Margin Calculation

The Corrected Amplitude is calculated by adding the Antenna Factor and Cable Factor, and subtracting the Amplifier Gain from the Amplitude reading. The basic equation is as follows:

Corr. Ampl. = Indicated Reading + Antenna Factor + Cable Factor - Amplifier Gain

The "Margin" column of the following data tables indicates the degree of compliance with the applicable limit. For example, a margin of  $-7dB\mu V$  means the emission is  $7dB\mu V$  below the maximum limit for Class B. The equation for margin calculation is as follows:

Margin = Corr. Ampl. – Class B Limit

### 7.7 Summary of Test Results

According to the data in section 7.10, the EUT complied with the FCC Part15 Paragraph 15.247 standards.

#### 7.8 EUT Operating Condition

Same as section 6.4 of this report.

Let the EUT work in test mode and test it.

### 7.9 Radiated Emissions Limit on Paragraph 15.209

Frequency(MHZ)	Distance(m)	Field strength(dBuV/m)
30-88	3	40.0
88-216	3	43.5
216-960	3	46.0
Above 960	3	54.0

Note:

- (1) RF Voltage(dBuV)=20 log RF Voltage(uV)
- (2) In the Above Table, the tighter limit applies at the band edges.
- (3) Distance refers to the distance in meters between the measuring instrument antenna.
- (4)The emission limit in this paragraph is based on measurement instrumentation employing an average detector. Measurement using instrumentation with a peak detector function, corresponding to 20dB above the maximum permitted average limit.
- (5)Above 1GHz,do a Peak and average measurements for all emissions,Limit for peak is 74dBuvV/m,According to Part15.35(b) and average is 54BuvV/m.

#### 7.10 Radiated Emissions Test Result

Formula of conversion factors:the field strength at 3m was egtablished by adding The meter reading of the spectrum analyer (which is set to read in units of dBuV) To the antenna correction factor supplied by the antenna manufacturer. The antenna Correction factors are stared in terms of dB. The gain of the pressletor was accounted For in the spectrum analyser meter reading.

Example:

Freq(MHz) Meter Reading +ACF=FS

33 20dBuV+10.36dB=30.36dBuV/m @3m

#### 7.11 Radiated Emission Data

A. Test Item: Radiated Emission Data

Test Voltage: 120VAC
Test Mode: TX On
Temperature: 24 °C
Humidity: 52%RH
Test Result: PASS

Remarks: 30-1000MHz radiation test no significant emissions above the equipment noise floor were detected.

Frequenc y (MHz)	Detect or	Antenna Polarizat ion	Emissio n Level (dBuV/ m)	FCC 15 Subpart C Limit (dBuV/m)	Margin (dB)	Antenna Height (m)	Turntab le Angle (°)					
	Low frequency											
2402.00	AV	Vertical	91.57		(Fund.)	1.5	90					
4804.00	AV	Vertical	30.74	54.00	23.26	1.5	120					
7206.00	AV	Vertical	30.33	54.00	23.67	1.8	100					
9608.00	AV	Vertical	30.47	54.00	23.53	1.5	90					
12010.00	AV	Vertical	30.21	54.00	23.79	1.0	60					
14412.00	AV	Vertical	30.49	54.00	23.51	1.5	60					
16814.00	AV	Vertical	30.28	54.00	23.72	1.8	100					
19216.00	AV	Vertical	30.67	54.00	23.33	1.8	180					
21618.00	AV	Vertical	30.59	54.00	23.41	1.5	100					
24020.00	AV	Vertical	30.73	54.00	23.27	1.0	45					

2402.00	AV	Horizontal	97.36		(Fund.)	1.5	45			
4804.00	AV	Horizontal	32.45	54.00	21.55	1.6	180			
7206.00	AV	Horizontal	32.16	54.00	21.84	1.5	60			
9608.00	AV	Horizontal	32.03	54.00	21.97	1.0	90			
12010.00	AV	Horizontal	34.21	54.00	19.79	1.8	45			
14412.00	AV	Horizonta	30.36	54.00	23.64	1.0	120			
16814.00	AV	Horizontal	30.74	54.00	23.26	1.8	180			
19216.00	AV	Horizontal	31.22	54.00	22.78	1.5	90			
21618.00	AV	Horizontal	32.53	54.00	21.47	1.5	60			
24020.00	AV	Horizontal	30.36	54.00	23.64	1.0	60			
2402.00	PK	Vertical	102.68		(Fund.)	1.5	90			
4804.00	PK	Vertical	43.64	74.00	30.36	1.5	100			
7206.00	PK	Vertical	37.88	74.00	36.12	1.8	120			
9608.00	PK	Vertical	37.42	74.00	36.58	1.8	100			
12010.00	PK	Vertical	35.63	74.00	38.37	1.0	90			
14412.00	PK	Vertical	37.77	74.00	36.23	1.8	90			
16814.00	PK	Vertical	35.89	74.00	38.11	1.0	60			
19216.00	PK	Vertical	38.67	74.00	35.33	1.8	100			
21618.00	PK	Vertical	38.78	74.00	35.22	1.5	120			
24020.00	PK	Vertical	34.31	74.00	39.69	1.5	45			
2402.00	PK	Horizontal	102.79		(Fund.)	1.5	45			
4804.00	PK	Horizontal	40.21	74.00	39.79	1.6	60			
7206.00	PK	Horizontal	35.76	74.00	38.24	1.5	100			
9608.00	PK	Horizontal	37.33	74.00	36.67	1.0	90			
12010.00	PK	Horizontal	33.19	74.00	40.81	1.0	60			
14412.00	PK	Horizontal	33.62	74.00	40.38	1.5	60			
16814.00	PK	Horizontal	30.73	74.00	43.27	1.8	100			
19216.00	PK	Horizontal	33.57	74.00	40.43	1.8	120			
21618.00	PK	Horizontal	33.39	74.00	40.61	1.8	180			
24020.00	PK	Horizontal	35.68	74.00	38.32	1.0	120			
	Middle frequency									
2441.00	AV	Vertical	85.37		(Fund.)	1.5	90			
4882.00	AV	Vertical	30.91	54.00	23.09	1.5	45			
7323.00	AV	Vertical	30.42	54.00	23.58	1.6	60			
1525.00	7 1 V	, crucar	50.74	27.00	23.30	1.0				

9764.00         AV         Vertical         30.33         54.00         22.67         1.0         100           12205.00         AV         Vertical         30.23         54.00         22.77         1.8         180           14646.00         AV         Vertical         30.37         54.00         23.63         1.0         120           17087.00         AV         Vertical         30.26         54.00         23.74         1.6         100           19528.00         AV         Vertical         30.17         54.00         23.83         1.6         180           21969.00         AV         Vertical         33.65         54.00         20.35         1.5         90           2441.00         AV         Horizontal         86.25         (Fund.)         1.5         100           4882.00         AV         Horizontal         32.94         54.00         21.06         1.5         180           7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           1205.00 <t< th=""><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th></th></t<>								
14646.00         AV         Vertical         30.37         54.00         23.63         1.0         120           17087.00         AV         Vertical         30.26         54.00         23.74         1.6         100           19528.00         AV         Vertical         30.17         54.00         23.83         1.6         180           21969.00         AV         Vertical         33.65         54.00         20.35         1.5         90           2441.00         AV         Vertical         33.86         54.00         20.14         1.0         45           2441.00         AV         Horizontal         86.25         (Fund.)         1.5         100           4882.00         AV         Horizontal         32.94         54.00         21.06         1.5         180           7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           14646.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         <	9764.00	AV	Vertical	30.33	54.00	22.67	1.0	100
17087.00         AV         Vertical         30.26         54.00         23.74         1.6         100           19528.00         AV         Vertical         30.17         54.00         23.83         1.6         180           21969.00         AV         Vertical         33.65         54.00         20.35         1.5         90           2441.00         AV         Vertical         33.86         54.00         20.14         1.0         45           2441.00         AV         Horizontal         86.25         (Fund.)         1.5         100           4882.00         AV         Horizontal         32.94         54.00         21.06         1.5         180           7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           12205.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00	12205.00	AV	Vertical	30.23	54.00	22.77	1.8	180
19528.00         AV         Vertical         30.17         54.00         23.83         1.6         180           21969.00         AV         Vertical         33.65         54.00         20.35         1.5         90           24410.00         AV         Vertical         33.86         54.00         20.14         1.0         45           2441.00         AV         Horizontal         86.25         (Fund.)         1.5         100           4882.00         AV         Horizontal         32.94         54.00         21.06         1.5         180           7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           1205.00         AV         Horizontal         30.67         54.00         22.50         1.8         120           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           24410.00	14646.00	AV	Vertical	30.37	54.00	23.63	1.0	120
21969.00         AV         Vertical         33.65         54.00         20.35         1.5         90           2441.00         AV         Vertical         33.86         54.00         20.14         1.0         45           2441.00         AV         Horizontal         36.25         (Fund.)         1.5         100           4882.00         AV         Horizontal         32.94         54.00         21.06         1.5         180           7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         32.52         54.00         22.50         1.8         120           12205.00         AV         Horizontal         30.67         54.00         22.50         1.8         120           14646.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         30.59         54.00         22.14         1.8         180           21969.00         AV         Horizontal         30.57         54.00         23.41         1.6         120           2441.00	17087.00	AV	Vertical	30.26	54.00	23.74	1.6	100
24410.00         AV         Vertical         33.86         54.00         20.14         1.0         45           2441.00         AV         Horizontal         86.25         (Fund.)         1.5         100           4882.00         AV         Horizontal         32.94         54.00         21.06         1.5         180           7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         32.52         54.00         21.48         1.0         100           12205.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           14646.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           24410.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           24410.00	19528.00	AV	Vertical	30.17	54.00	23.83	1.6	180
2441.00         AV         Horizontal         86.25         (Fund.)         1.5         100           4882.00         AV         Horizontal         32.94         54.00         21.06         1.5         180           7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         32.52         54.00         21.48         1.0         100           12205.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           14646.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           24410.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK	21969.00	AV	Vertical	33.65	54.00	20.35	1.5	90
4882.00         AV         Horizontal         32.94         54.00         21.06         1.5         180           7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         32.52         54.00         21.48         1.0         100           12205.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           14646.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         31.86         54.00         22.14         1.8         180           21969.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           2441.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           4882.00         PK         Vertical         10.37         74.00         33.63         1.5         60	24410.00	AV	Vertical	33.86	54.00	20.14	1.0	45
7323.00         AV         Horizontal         31.33         54.00         22.67         1.8         90           9764.00         AV         Horizontal         32.52         54.00         21.48         1.0         100           12205.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           14646.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         31.86         54.00         22.14         1.8         180           21969.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           2441.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00	2441.00	AV	Horizontal	86.25		(Fund.)	1.5	100
9764.00         AV         Horizontal         32.52         54.00         21.48         1.0         100           12205.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           14646.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         31.86         54.00         22.14         1.8         180           21969.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           2441.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         37.28         74.00         33.63         1.5         60           7323.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00	4882.00	AV	Horizontal	32.94	54.00	21.06	1.5	180
12205.00         AV         Horizontal         31.50         54.00         22.50         1.8         120           14646.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         31.86         54.00         22.14         1.8         180           21969.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           2441.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         37.28         74.00         33.63         1.5         60           7323.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         38.36         74.00         36.13         1.5         120           19528.00	7323.00	AV	Horizontal	31.33	54.00	22.67	1.8	90
14646.00         AV         Horizontal         30.67         54.00         23.33         1.6         90           17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         31.86         54.00         22.14         1.8         180           21969.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           24410.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         40.37         74.00         33.63         1.5         60           7323.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00         PK         Vertical         36.94         74.00         36.13         1.5         120           1205.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         <	9764.00	AV	Horizontal	32.52	54.00	21.48	1.0	100
17087.00         AV         Horizontal         30.24         54.00         23.76         1.5         45           19528.00         AV         Horizontal         31.86         54.00         22.14         1.8         180           21969.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           2441.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         40.37         74.00         33.63         1.5         60           7323.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         <	12205.00	AV	Horizontal	31.50	54.00	22.50	1.8	120
19528.00         AV         Horizontal         31.86         54.00         22.14         1.8         180           21969.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           24410.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         40.37         74.00         33.63         1.5         60           7323.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         38.36         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         <	14646.00	AV	Horizontal	30.67	54.00	23.33	1.6	90
21969.00         AV         Horizontal         30.59         54.00         23.41         1.6         120           2441.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         40.37         74.00         33.63         1.5         60           7323.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         PK         Vertical         39.47         74.00         34.15         1.5         120           19528.00         PK         Vertical         39.85         74.00         33.78         1.6         45           24410.00         PK	17087.00	AV	Horizontal	30.24	54.00	23.76	1.5	45
24410.00         AV         Horizontal         30.71         54.00         23.29         1.0         120           2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         40.37         74.00         33.63         1.5         60           7323.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         45.61         74.00         33.78         1.6         45           24410.00         PK<	19528.00	AV	Horizontal	31.86	54.00	22.14	1.8	180
2441.00         PK         Vertical         101.87         (Fund.)         1.5         120           4882.00         PK         Vertical         40.37         74.00         33.63         1.5         60           7323.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK	21969.00	AV	Horizontal	30.59	54.00	23.41	1.6	120
4882.00         PK         Vertical         40.37         74.00         33.63         1.5         60           7323.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         44.68         74.00         29.32         1.8         45           7323.00 <td>24410.00</td> <td>AV</td> <td>Horizontal</td> <td>30.71</td> <td>54.00</td> <td>23.29</td> <td>1.0</td> <td>120</td>	24410.00	AV	Horizontal	30.71	54.00	23.29	1.0	120
7323.00         PK         Vertical         37.28         74.00         36.72         1.5         90           9764.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         32.59         1.5         60           9764.00         PK<	2441.00	PK	Vertical	101.87		(Fund.)	1.5	120
9764.00         PK         Vertical         36.94         74.00         37.06         1.6         100           12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00	4882.00	PK	Vertical	40.37	74.00	33.63	1.5	60
12205.00         PK         Vertical         37.87         74.00         36.13         1.5         120           14646.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         35.26         1.0         120	7323.00	PK	Vertical	37.28	74.00	36.72	1.5	90
14646.00         PK         Vertical         38.36         74.00         35.64         1.8         90           17087.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         29.32         1.8         45           7323.00         PK         Horizontal         41.41         74.00         32.59         1.5         60           9764.00         PK         Horizontal         39.36         74.00         33.76         1.5         90           12205.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	9764.00	PK	Vertical	36.94	74.00	37.06	1.6	100
17087.00         PK         Vertical         39.47         74.00         34.53         1.0         180           19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         29.32         1.8         45           7323.00         PK         Horizontal         41.41         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	12205.00	PK	Vertical	37.87	74.00	36.13	1.5	120
19528.00         PK         Vertical         39.85         74.00         34.15         1.5         120           21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         29.32         1.8         45           7323.00         PK         Horizontal         41.41         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	14646.00	PK	Vertical	38.36	74.00	35.64	1.8	90
21969.00         PK         Vertical         40.22         74.00         33.78         1.6         45           24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         29.32         1.8         45           7323.00         PK         Horizontal         41.41         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	17087.00	PK	Vertical	39.47	74.00	34.53	1.0	180
24410.00         PK         Vertical         45.61         74.00         28.39         1.8         90           2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         29.32         1.8         45           7323.00         PK         Horizontal         41.41         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	19528.00	PK	Vertical	39.85	74.00	34.15	1.5	120
2441.00         PK         Horizontal         101.89         (Fund.)         1.5         100           4882.00         PK         Horizontal         44.68         74.00         29.32         1.8         45           7323.00         PK         Horizontal         41.41         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	21969.00	PK	Vertical	40.22	74.00	33.78	1.6	45
4882.00         PK         Horizontal         44.68         74.00         29.32         1.8         45           7323.00         PK         Horizontal         41.41         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	24410.00	PK	Vertical	45.61	74.00	28.39	1.8	90
7323.00         PK         Horizontal         41.41         74.00         32.59         1.5         60           9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	2441.00	PK	Horizontal	101.89		(Fund.)	1.5	100
9764.00         PK         Horizontal         40.24         74.00         33.76         1.5         90           12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	4882.00	PK	Horizontal	44.68	74.00	29.32	1.8	45
12205.00         PK         Horizontal         39.36         74.00         34.64         1.6         100           14646.00         PK         Horizontal         38.74         74.00         35.26         1.0         120	7323.00	PK	Horizontal	41.41	74.00	32.59	1.5	60
14646.00 PK Horizontal 38.74 74.00 35.26 1.0 120	9764.00	PK	Horizontal	40.24	74.00	33.76	1.5	90
	12205.00	PK	Horizontal	39.36	74.00	34.64	1.6	100
17087.00 PK Horizontal 36.82 74.00 37.18 1.8 180	14646.00	PK	Horizontal	38.74	74.00	35.26	1.0	120
	17087.00	PK	Horizontal	36.82	74.00	37.18	1.8	180

19528.00															
24410.00         PK         Horizontal         41.67         74.00         32.33         1.6         45           High frequency           2480.00         AV         Vertical         86.73         (Fund.)         1.5         100           4960.00         AV         Vertical         31.26         54.00         22.74         1.5         45           7440.00         AV         Vertical         31.26         54.00         22.27         1.5         120           9920.00         AV         Vertical         31.26         54.00         22.74         1.6         90           12400.00         AV         Vertical         30.45         54.00         23.55         1.8         45           14880.00         AV         Vertical         30.44         54.00         23.56         1.5         100           17360.00         AV         Vertical         30.13         54.00         22.38         1.6         120           19840.00         AV         Vertical         30.27         54.00         23.73         1.5         90           2480.00         AV         Horizontal         31.95         54.00         23.16         1.5	19528.00	PK	Horizontal	38.86	74.00	35.14	1.5	120							
High frequency	21969.00	PK	Horizontal	40.22	74.00	33.78	1.5	100							
2480.00         AV         Vertical         86.73         (Fund.)         1.5         100           4960.00         AV         Vertical         31.26         54.00         22.74         1.5         45           7440.00         AV         Vertical         31.73         54.00         22.27         1.5         120           9920.00         AV         Vertical         31.26         54.00         22.74         1.6         90           12400.00         AV         Vertical         30.45         54.00         23.55         1.8         45           14880.00         AV         Vertical         30.44         54.00         23.56         1.5         100           17360.00         AV         Vertical         30.13         54.00         22.38         1.6         120           19840.00         AV         Vertical         30.27         54.00         23.73         1.5         90           22320.00         AV         Vertical         30.84         54.00         23.16         1.5         60           2480.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV	24410.00	PK	Horizontal	41.67	74.00	32.33	1.6	45							
4960.00         AV         Vertical         31.26         54.00         22.74         1.5         45           7440.00         AV         Vertical         31.73         54.00         22.27         1.5         120           9920.00         AV         Vertical         31.26         54.00         22.74         1.6         90           12400.00         AV         Vertical         30.45         54.00         23.55         1.8         45           14880.00         AV         Vertical         30.44         54.00         23.56         1.5         100           17360.00         AV         Vertical         30.13         54.00         22.38         1.6         120           19840.00         AV         Vertical         30.27         54.00         23.87         1.8         90           22320.00         AV         Vertical         30.27         54.00         23.16         1.5         60           24800.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.35         54.00         22.05         1.5         100           7440.00         AV </td <td></td> <td colspan="14">High frequency</td>		High frequency													
7440.00         AV         Vertical         31.73         54.00         22.27         1.5         120           9920.00         AV         Vertical         31.26         54.00         22.74         1.6         90           12400.00         AV         Vertical         30.45         54.00         23.55         1.8         45           14880.00         AV         Vertical         30.44         54.00         23.56         1.5         100           17360.00         AV         Vertical         30.13         54.00         22.38         1.6         120           19840.00         AV         Vertical         30.13         54.00         23.87         1.8         90           22320.00         AV         Vertical         30.27         54.00         23.73         1.5         90           2480.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.35         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.57         54.00         22.43         1.0         60           12400.00         AV	2480.00	AV	Vertical	86.73		(Fund.)	1.5	100							
9920.00         AV         Vertical         31.26         54.00         22.74         1.6         90           12400.00         AV         Vertical         30.45         54.00         23.55         1.8         45           14880.00         AV         Vertical         30.44         54.00         23.56         1.5         100           17360.00         AV         Vertical         30.13         54.00         22.38         1.6         120           19840.00         AV         Vertical         30.13         54.00         22.387         1.8         90           22320.00         AV         Vertical         30.27         54.00         23.73         1.5         90           24800.00         AV         Vertical         30.84         54.00         23.16         1.5         60           2480.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.57         54.00         22.43         1.0         60           12400.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.	4960.00	AV	Vertical	31.26	54.00	22.74	1.5	45							
12400.00         AV         Vertical         30.45         54.00         23.55         1.8         45           14880.00         AV         Vertical         30.44         54.00         23.56         1.5         100           17360.00         AV         Vertical         31.62         54.00         22.38         1.6         120           19840.00         AV         Vertical         30.13         54.00         23.87         1.8         90           22320.00         AV         Vertical         30.27         54.00         23.73         1.5         90           2480.00         AV         Vertical         30.84         54.00         23.16         1.5         60           2480.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.57         54.00         22.43         1.0         60           12400.00         AV         Horizontal         31.79         54.00         22.158         1.0         100           17360.00 <t< td=""><td>7440.00</td><td>AV</td><td>Vertical</td><td>31.73</td><td>54.00</td><td>22.27</td><td>1.5</td><td>120</td></t<>	7440.00	AV	Vertical	31.73	54.00	22.27	1.5	120							
14880.00         AV         Vertical         30.44         54.00         23.56         1.5         100           17360.00         AV         Vertical         31.62         54.00         22.38         1.6         120           19840.00         AV         Vertical         30.13         54.00         23.87         1.8         90           22320.00         AV         Vertical         30.27         54.00         23.73         1.5         90           2480.00         AV         Vertical         30.84         54.00         23.16         1.5         60           2480.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.57         54.00         22.65         1.5         90           9920.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         30.55         54.00         21.58         1.0         100           17360.00 <t< td=""><td>9920.00</td><td>AV</td><td>Vertical</td><td>31.26</td><td>54.00</td><td>22.74</td><td>1.6</td><td>90</td></t<>	9920.00	AV	Vertical	31.26	54.00	22.74	1.6	90							
17360.00         AV         Vertical         31.62         54.00         22.38         1.6         120           19840.00         AV         Vertical         30.13         54.00         23.87         1.8         90           22320.00         AV         Vertical         30.27         54.00         23.73         1.5         90           24800.00         AV         Vertical         30.84         54.00         23.16         1.5         60           2480.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.57         54.00         22.65         1.5         90           9920.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         31.17         54.00         22.83         1.8         120           19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00	12400.00	AV	Vertical	30.45	54.00	23.55	1.8	45							
19840.00         AV         Vertical         30.13         54.00         23.87         1.8         90           22320.00         AV         Vertical         30.27         54.00         23.73         1.5         90           24800.00         AV         Vertical         30.84         54.00         23.16         1.5         60           2480.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.57         54.00         22.65         1.5         90           9920.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         32.42         54.00         21.58         1.0         100           17360.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         33.25         54.00         21.14         1.0         100           2480.00	14880.00	AV	Vertical	30.44	54.00	23.56	1.5	100							
22320.00         AV         Vertical         30.27         54.00         23.73         1.5         90           24800.00         AV         Vertical         30.84         54.00         23.16         1.5         60           2480.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.35         54.00         22.65         1.5         90           9920.00         AV         Horizontal         31.77         54.00         22.43         1.0         60           12400.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         31.17         54.00         21.58         1.0         100           17360.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         33.25         54.00         21.14         1.0         100           2480.00	17360.00	AV	Vertical	31.62	54.00	22.38	1.6	120							
24800.00         AV         Vertical         30.84         54.00         23.16         1.5         60           2480.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.35         54.00         22.65         1.5         90           9920.00         AV         Horizontal         31.57         54.00         22.43         1.0         60           12400.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         32.42         54.00         21.58         1.0         100           17360.00         AV         Horizontal         30.55         54.00         22.83         1.8         120           19840.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           24800.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           4960.00	19840.00	AV	Vertical	30.13	54.00	23.87	1.8	90							
2480.00         AV         Horizontal         87.74         (Fund.)         1.5         180           4960.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.35         54.00         22.65         1.5         90           9920.00         AV         Horizontal         31.57         54.00         22.43         1.0         60           12400.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         32.42         54.00         21.58         1.0         100           17360.00         AV         Horizontal         30.55         54.00         22.83         1.8         120           19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           24800.00         PK         Vertical         39.75         74.00         34.25         1.5         100           7440.00	22320.00	AV	Vertical	30.27	54.00	23.73	1.5	90							
4960.00         AV         Horizontal         31.95         54.00         22.05         1.5         100           7440.00         AV         Horizontal         31.35         54.00         22.65         1.5         90           9920.00         AV         Horizontal         31.57         54.00         22.43         1.0         60           12400.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         32.42         54.00         21.58         1.0         100           17360.00         AV         Horizontal         30.55         54.00         22.83         1.8         120           19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           2480.00         PK         Vertical         37.83         74.00         34.25         1.5         100           7440.00	24800.00	AV	Vertical	30.84	54.00	23.16	1.5	60							
7440.00         AV         Horizontal         31.35         54.00         22.65         1.5         90           9920.00         AV         Horizontal         31.57         54.00         22.43         1.0         60           12400.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         32.42         54.00         21.58         1.0         100           17360.00         AV         Horizontal         31.17         54.00         22.83         1.8         120           19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           2480.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           4960.00         PK         Vertical         37.83         74.00         34.25         1.5         100           7440.00	2480.00	AV	Horizontal	87.74		(Fund.)	1.5	180							
9920.00         AV         Horizontal         31.57         54.00         22.43         1.0         60           12400.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         32.42         54.00         21.58         1.0         100           17360.00         AV         Horizontal         31.17         54.00         22.83         1.8         120           19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           24800.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           4960.00         PK         Vertical         37.83         74.00         34.25         1.5         100           7440.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00	4960.00	AV	Horizontal	31.95	54.00	22.05	1.5	100							
12400.00         AV         Horizontal         31.79         54.00         22.21         1.6         90           14880.00         AV         Horizontal         32.42         54.00         21.58         1.0         100           17360.00         AV         Horizontal         31.17         54.00         22.83         1.8         120           19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           24800.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           2480.00         PK         Vertical         37.83         74.00         34.25         1.5         100           7440.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         39.28         1.6         60           17360.00	7440.00	AV	Horizontal	31.35	54.00	22.65	1.5	90							
14880.00         AV         Horizontal         32.42         54.00         21.58         1.0         100           17360.00         AV         Horizontal         31.17         54.00         22.83         1.8         120           19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           24800.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           4960.00         PK         Vertical         39.75         74.00         34.25         1.5         100           7440.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00	9920.00	AV	Horizontal	31.57	54.00	22.43	1.0	60							
17360.00         AV         Horizontal         31.17         54.00         22.83         1.8         120           19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           24800.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           4960.00         PK         Vertical         39.75         74.00         34.25         1.5         100           7440.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         <	12400.00	AV	Horizontal	31.79	54.00	22.21	1.6	90							
19840.00         AV         Horizontal         30.55         54.00         23.45         1.5         180           22320.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           24800.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           4960.00         PK         Vertical         39.75         74.00         34.25         1.5         100           7440.00         PK         Vertical         37.83         74.00         36.17         1.5         180           9920.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00	14880.00	AV	Horizontal	32.42	54.00	21.58	1.0	100							
22320.00         AV         Horizontal         32.86         54.00         21.14         1.0         100           24800.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           4960.00         PK         Vertical         39.75         74.00         34.25         1.5         100           7440.00         PK         Vertical         37.83         74.00         36.17         1.5         180           9920.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	17360.00	AV	Horizontal	31.17	54.00	22.83	1.8	120							
24800.00         AV         Horizontal         33.25         54.00         20.75         1.6         60           2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           4960.00         PK         Vertical         39.75         74.00         34.25         1.5         100           7440.00         PK         Vertical         37.83         74.00         36.17         1.5         180           9920.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         34.72         74.00         39.28         1.6         60           17360.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	19840.00	AV	Horizontal	30.55	54.00	23.45	1.5	180							
2480.00         PK         Vertical         101.42         (Fund.)         1.5         60           4960.00         PK         Vertical         39.75         74.00         34.25         1.5         100           7440.00         PK         Vertical         37.83         74.00         36.17         1.5         180           9920.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         34.72         74.00         39.28         1.6         60           17360.00         PK         Vertical         36.26         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	22320.00	AV	Horizontal	32.86	54.00	21.14	1.0	100							
4960.00         PK         Vertical         39.75         74.00         34.25         1.5         100           7440.00         PK         Vertical         37.83         74.00         36.17         1.5         180           9920.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         34.72         74.00         39.28         1.6         60           17360.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	24800.00	AV	Horizontal	33.25	54.00	20.75	1.6	60							
7440.00         PK         Vertical         37.83         74.00         36.17         1.5         180           9920.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         34.72         74.00         39.28         1.6         60           17360.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	2480.00	PK	Vertical	101.42		(Fund.)	1.5	60							
9920.00         PK         Vertical         36.39         74.00         37.61         1.8         90           12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         34.72         74.00         39.28         1.6         60           17360.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	4960.00	PK	Vertical	39.75	74.00	34.25	1.5	100							
12400.00         PK         Vertical         35.56         74.00         38.44         1.0         90           14880.00         PK         Vertical         34.72         74.00         39.28         1.6         60           17360.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	7440.00	PK	Vertical	37.83	74.00	36.17	1.5	180							
14880.00         PK         Vertical         34.72         74.00         39.28         1.6         60           17360.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	9920.00	PK	Vertical	36.39	74.00	37.61	1.8	90							
17360.00         PK         Vertical         36.87         74.00         37.13         1.8         45           19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	12400.00	PK	Vertical	35.56	74.00	38.44	1.0	90							
19840.00         PK         Vertical         36.26         74.00         37.74         1.5         100           22320.00         PK         Vertical         36.73         74.00         37.27         1.5         90	14880.00	PK	Vertical	34.72	74.00	39.28	1.6	60							
22320.00 PK Vertical 36.73 74.00 37.27 1.5 90	17360.00	PK	Vertical	36.87	74.00	37.13	1.8	45							
	19840.00	PK	Vertical	36.26	74.00	37.74	1.5	100							
24800.00 PK Vertical 36.33 74.00 37.67 1.6 60	22320.00	PK	Vertical	36.73	74.00	37.27	1.5	90							
	24800.00	PK	Vertical	36.33	74.00	37.67	1.6	60							

2480.00	PK	Vertical	101.05		(Fund.)	1.5	60
4960.00	PK	Vertical	40.57	74.00	33.43	1.5	90
7440.00	PK	Vertical	38.64	74.00	35.36	1.5	90
9920.00	PK	Vertical	35.37	74.00	38.63	1.6	90
12400.00	PK	Vertical	35.52	74.00	38.48	1.6	45
14880.00	PK	Vertical	35.26	74.00	38.74	1.5	60
17360.00	PK	Vertical	37.41	74.00	36.59	1.8	100
19840.00	PK	Vertical	38.25	74.00	35.75	1.8	120
22320.00	PK	Vertical	40.11	74.00	33.89	1.0	180
24800.00	PK	Vertical	40.62	74.00	33.38	1.6	60

# 8 Antenna Requirement.

According to the FCC Part 15 Paragraph 15.203, an intentional radiator shall be designed to ensure that no antenna other than that furnished by the responsible party shall be used with the device. The use of a permanently attached antenna to the intentional radiator shall be considered sufficient to comply with the provisions of this section. This product has a permanent antenna, fulfill the requirement of this section

### 9 Maximum Peak Output Power

Test Requirement: FCC Part15 Paragraph 15.247

Test Method: Based on ANSI 63.4:2003

Test Date: July 3, 2008

Test mode: Compliance test in the worse case: Tx Low/Tx Middle/Tx High

Requirements: Regulation 15.247(b) The limit of Maximum Peak Output

Power Measurement is 1W(30dBm)

### **Test procedure:**

The following test procedure as below:

The transmitter output (antenna port) was connected to the spectrum analyzer.EUT and its simulators are placed on a table, let EUT working in test mode, then test it.

The bandwidth of the fundamental frequency was measured with the spectrum analyser using 100kHz RBW and 100kHz VBW.

**Test Result:** The unit does meet the FCC requirements.

Test Channel	Fundamental Frequency(GHz)	Output Power (mW)	Limit (W)	Power output level
low	2.402	0.37	1	ERP
middle	2.441	0.32	1	ERP
high	2.480	0.28	1	ERP

# 10 Hopping Channel Number

Test Requirement: FCC Part15 C

Test Method: Based on FCC Part15 Paragraph 15.247

Test Date: July 3, 2008

Test mode: The EUT work in test mode(Tx) and test it

Requirements: Regulation 15.247(b) For frequency hopping systems operating


In the 2400-2483.5MHz band employing at least 75 hopping

channels.

Test result: The total number of channels would be 79 channels.

The unit does meet the FCC requirements.

Please refer the graph as below:



# 11 Carrier Frequencies Separated

Test Requirement: FCC Part15 C

Test Method: Based on FCC Part15 Paragraph 15.247

Test Date: July 3, 2008

Test mode: The EUT work in test mode(Tx) and test it

Requirements: The bandwidth of the fundamental frequency was measur by

spectrum analyser with 100kHz RBW and 100kHz VBW. The 20dB bandwidth is defined as the total spectrum the power of

which is higher than peak power minus 20dB.


Test result: PASS

### Channel Carrier Frequency Separated


Test Channel	Carrier Frequencies Separated	PASS/FAIL	
Lower Channels (channel 2402MHZ and channel 2403MHZ)	1MHz	Pass	
Lower Channels (channel 2441MHZ and channel 2442MHZ)	1MHz	Pass	
Lower Channels (channel 2479MHZ and channel 2480MHZ)	1MHz	Pass	

The unit does meet the FCC requirements.


### 11.1 Lower Channel: Carrier Frequencies Separated



### 11.2 Middle Channel: Carrier Frequencies Separated



### 11.3 Upper Channel: Carrier Frequencies Separated



Date: 3.JUL.2008 19:42:28

#### 12 Dwell Time

Test Requirement: FCC Part15 C

Test Method: Based on FCC Part15 Paragraph 15.247

Test Date: July 3, 2008

Test mode: The EUT work in test mode(Tx) and test it

Requirements: 15.247 a(1)(iii)Frequency hopping systems in the 2400-2483.5MHz band shall use at least 15 non-overlapping channels. The average time of occupancy on any channel shall not greater than 0.4 seconds within a period of 0.4 seconds multiplied by the number of hopping channels employed.

### **12.1** Test procedure

The transmitter output (antenna port) was connected to the spectrum analyzer.EUT and its simulators are placed on a table, let EUT working in test mode, then test it.

The bandwidth of the fundamental frequency was measured with the spectrum analyser using 100kHz RBW and 100kHz VBW,set sweep time:10 ms.Span:0Hz.

#### 12.2 Test Results: PASS

Number of hopping channels is 79.

A channel was used 107 times within 0.4\*79=31.6S.

Dwell time of each occupation in this channel a follows:

1.Low Channel: 1.55 mS \* 107=0.1659S < 0.4 s


2.Middle Channel: 1.95 mS \* 107 = 0.2087 S < 0.4 s

3.High Channel: 1.775 mS \* 107 = 0.1899S < 0.4 s


The Results are not be greater than 0.4 seconds.

Please refer the graph as below:


### **Channel 0: 2. 402GHz**



### **Channel 27: 2.441GHz**



### **Channel 55: 2.480GHz**



### 13 20-dB Bandwith

Test Requirement: FCC Part15 C

Test Method: Based on FCC Part15 Paragraph 15.247

Test Date: July 3, 2008

Test mode: The EUT work in test mode(Tx) and test it

#### 13.1 Test Procedure


1. The transmitter output (antenna port) was connected to the spectrum analyzer.

2. The bandwidth of the fundamental frequency was measure by spectrum analyser with 100KHz RBW and 100KHz VBW. The 20dB bandwidth is defined as the total spectrum the power of which is higher than peak power 20dB.


### 13.2 Test Result

Please refer the graph as below:


### Low



### Middle



## High



### 14 Radiated spurious emissions into adjacent restricted band

Test Requirement: FCC Part15 Paragraph 15.205


Test Method: Based on FCC Part 15 Paragraph 15.247


Test Date: July 3, 2008

Requirements: The EUT work in test mode(Tx) and test it

**Requiments:** emissions that fall in the restricted bands(15.205). Above 1000MHz, compliance with the emissions limits in section 15.209 shall be demonstrated based on the average value of the measured emissions, The provisions in section 15.35 apply to these measurements.


**Test procedure:**An in band field strength measurement of the fundamental emission using the RBW and detector function required by C63.4-2003 and FCC Rules. The procedure was repeated with an average detector and a plot made. The calculated field strength in the adjacent restricted band is presented below.





•

### upper bandedge/ restricted band (peak value)



### 15 RF Exposure Test

Test Requirement: FCC Part 2 Subpart J

Test Method: Based on FCC Part 15 Paragraph 15.247

Test Date: July.3, 2008

Requirements: The EUT work in test mode(Tx) and test it

**Requiments:**Systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy levels in excess limit for maximum permissible exposure. In accordance with 47 CFR FCC Part 2 Subpart J, section 2.1091 this device has been defined as a mobile device whereby a distance of 0.2 m normally can be maintained between the user and the device.

### The procedures / limit

(A) Limits for Occupational / Controlled Exposure

Frequency Range (MHz)	Electric Field Strength (E) (V/m)	Magnetic Field Strength (H) (A/m)	Power Density (S) (mW/ cm <sup>2</sup> )	Averaging Time  E  <sup>2</sup> , H  <sup>2</sup> or S (minutes)
0.3-3.0	614	1.63	(100)*	6
3.0-30	1842 / f	4.89 / f	(900 / f)*	6
30-300	61.4	0.163	1.0	6
300-1500			F/300	6
1500-100,000			5	6

(B) Limits for General Population / Uncontrolled Exposure

Frequency Range (MHz)	Electric Field Strength (E) (V/m)	Magnetic Field Strength (H) (A/m)	Power Density (S) (mW/ cm <sup>2</sup> )	Averaging Time $ E ^2$ , $ H ^2$ or S (minutes)
0.3-1.34	614	1.63	(100)*	30
1.34-30	824/f	2.19/f	(180/f)*	30
30-300	27.5	0.073	0.2	30
300-1500			F/1500	30
1500-100,000			1.0	30

Note: f = frequency in MHz; \*Plane-wave equivalent power density

### **MPE Calculation Method**

$$E (V/m) = \frac{\sqrt{30 \times P \times G}}{d}$$
 Power Density:  $Pd (W/m^2) = \frac{E^2}{377}$ 

 $\mathbf{E} = \text{Electric field (V/m)}$ 

 $\mathbf{P} = \text{Peak RF output power (W)}$ 

G = EUT Antenna numeric gain (numeric)

 $\mathbf{d} =$ Separation distance between radiator and human body (m)

The formula can be changed to


$$Pd = \frac{30 \times P \times G}{377 \times d^2}$$

From the peak EUT RF output power, the minimum mobile separation distance, d=0.2m, as well as the gain of the used antenna, the RF power density can be obtained


Antenna Gain (dBi)	Antenna Gain (numeric)	Peak Output Power (dBm)	Peak Output Power (mW)	Power Density (S) (mW/cm2)	Dencity (S)	Test Result
1.52	1.4191	-4.32	0.37	0.001474	1	Complies
1.52	1.4191	-4.94	0.32	0.001324	1	Complies
1.52	1.4191	-5.53	0.28	0.00137	1	Complies

# 16 Photographs of Testing

### 16.1 Radiation Emission Test View For 30MHz-1000MHz



### 16.2 Radiation Emission Test View For 1GHz-25GHz



## 16.3 Photographs - Conduction Radiation Test Setup



# 17 Photographs - Constructional Details


### 17.1 EUT– Front View




### 17.2 EUT– Back View




### 17.3 EUT PCB –Front View




### 17.4 EUT PCB –Back View



### 17.5 EUT PCB –Front View




## 17.6 EUT PCB –Back View




## 17.7 Adapter PCB– Front View




## 17.8 Adapter PCB- Back View



## 17.9 Car Charger Adapter PCB –Front View



# 17.10 Car Charger Adapter PCB-Back View



### 18 FCC ID Label

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference,and (2) this device must accept any interference received, including interference that may cause undesired operation.

The Label must not be a stick-on paper. The Label on these products must be permanently affixed to the product and readily visible at the time of purchase and must last the expected lifetime of the equipment not be readily detachable.

Proposed Label Location on EUT
EUT Bottom View/proposed FCC Mark Location

